

Syncrolite **Arena Color** Commands

(0-255 Decimal Values)

To Strike Lamp

Step One: Set Channel 3 (Command Word) to 43

Step Two: Set Channel 4 (Command Execute) to 86

Step Three: Set Channel 4 (Command Execute) to 171

To Kill Lamp

Step One: Set Channel 3 (Command Word) to 85

Step Two: Set Channel 4 (Command Execute) 86

Step Three: Set Channel 4 (Command Execute) 171

To Reset Fixture

Step One: Set Channel 3 (Command Word) to 169

Step Two: Set Channel 4 (Command Word) to 86

Step Three: Set Channel 4 (Command Word) to 171