

Syncrolite Arena Color

DMX Channels		5			
DMX Channels Per Universe		102			
Channel			Start	End	Function
1	Dimmer	Coarse Adjustment	0	255	0-100%
2	Color 1	Coarse Adjustment	0	255	0-100%
3	Command	Lamp on	43	43	
3	Command	Lamp off	85	85	
3	Command	Reset	169	169	
4	Control	Set up	86	86	
4	Control	Execute command	171	171	
5	Color 2	Coarse Adjustment	0	255	0-100%
Note:					

Channels 3&4: (Example Lamp On)

"Step 1 " Command Channel =43 " Control Channel = 86

"Step 2 " Command Channel =43 " Control Channel =171

The two steps can be .3 seconds apart. Every command that the light does needs the control channel to do the two steps while the command channel stays at the correct DMX value for that command.

Here is a list of the correct DMX values for each Command.

Lamp On=43

Lamp Off=85

Reset=169